## DEPARTMENT OF THE NAVY



BOARD OF INSPECTION AND SURVEY 2600 TARAWA COURT SUITE 250 VIRGINIA BEACH, VA 23459-3295

> INSURVINST 4730.74 25 July 2012

## INSURV INSTRUCTION 4730.74

FROM: PRESIDENT, BOARD OF INSPECTION AND SURVEY

SUBJ: SUBMARINE DYNAMIC ELECTRIC PLANT DEMONSTRATION

- 1. <u>Purpose</u>. To establish the President, Board of Inspection and Survey (PRESINSURV) policy and standards for evaluating the dynamic features of a submarine's electric plant.
- 2. <u>Discussion</u>. Electric plant functional demonstrations will be conducted for all submarine Material Inspections (MIs) and Combined Trials (CTs). All start-up checks will be conducted via Standard Operation only for each machine. All load sharing will be conducted via Standard Operation for each machine. Equipment to be demonstrated includes:
  - a. Ship's Service Turbine Generators
    - (1) Over-speed trip demonstration per applicable MRC.
- (2) Start-up checks including governor response per applicable Steam and Electric Plant Manual.
- (3) Electric plant load sharing during electric plant line-up changes per applicable Steam and Electric Plant Manual.
- (4) Operation at maximum attainable load per applicable Steam and Electric Plant Manual during the Full Power Demonstration.
  - b. Ship's Service Motor Generators (when applicable)
    - (1) Over-speed trip check per applicable MRC.
- (2) Start-up checks per applicable Steam and Electric Plant Manual.
- (3) Electric plant load sharing during electric plant line-up changes per applicable Steam and Electric Plant Manual.
  - c. Emergency Diesel Generator

- (1) Snorkel at full load while submerged.
- (2) Align and test spare governor per Diesel Technical Manual and applicable MRC.
- (3) Over-speed and under-frequency trip checks per applicable MRC.
- (4) Electric plant load sharing during electric plant line-up changes per applicable Steam and Electric Plant Manual.
- d. Ship's Main Storage Battery. Test discharge performance administrative review.
- 3. <u>Policy</u>. Dynamic electric plant operations will be conducted on all MIs and CTs.
- 4. <u>Pre-Inspection Requirement</u>. Conduct of these demonstrations require no additional pre-inspection actions by the ship beyond those specified in OPNAVINST 4730.2 (series) and the inspection services message sent approximately 45 days prior to the inspection.
- 5. The ship's Commanding Officer remains completely responsible for the safe conduct of these demonstrations. Nothing is more important than safety of personnel and equipment.

//s// R. O. WRAY

Distribution:
COMFLTFORCOM NORFOLK VA
COMPACFLT PEARL HARBOR HI
NAVSEA 08
COMSUBLANT NORFOLK VA
COMSUBPAC PEARL HARBOR HI
CNO(N87)
NAVSEA PMS 392
NAVSEA PMS 450